

## How to install the Aduro Air Booster

**Time to install:** 20 min

**Difficulty:** Easy

**Components:** 1 120 mm fan and 4 M4x60 screws




To obtain a better air flow in your Aduro Hybrid stove, you can install an Aduro Air Booster which is a supplementary fan for the stove. Please follow this guideline to install the Air Booster.

**IMPORTANT! UNPLUG THE STOVE BEFORE PERFORMING ANY INSTALLATION OR MAINTENANCE.**

1. Remove the backplate of the stove by unscrewing the 2 screws on each side of the backplate:



2. Unscrew the 4 screws on the air duct to locate the fan:




3. Place the Air Booster behind the stove's current fan and make sure that the air flow indicator arrows are pointing in the same direction and towards the middle of the stove:



4. Mount the two fans and the air duct with the screws included in the package from the Air Booster:



5. Connect the Air Booster to the two free slots in the white electric socket for the fans, one in each slot marked N and L:



6. To make sure the connection is tight, you can gently pull the cables.
7. Remount the backplate. You have now installed the Air Booster successfully.